SONY

LCS-TWP/L

Compact Carrying Case

Semi-hard front and soft backed case helps protect select Cyber-shot® cameras. Includes pouch for memory cards and spare battery. Hand carry or slide onto a belt through the attached belt loop.

Key Features

Protective case

Semi-hard front and soft padded back case helps protect your compatible Cyber-shot® camera

Hand/belt carry

Easily carry by hand, or slip a belt through the belt loop

Internal pocket

Handy internal pocket to store extra memory cards and a spare battery.

Available colors

Available in black, blue, and pink

Material

Nylon

Dimensions

3 1/2 x 5 1/4 x 1 3/16in (86 x 131 x 29mm)

Weight

1.8 oz (49g)

Specifications

Weights and Measurements	
Dimensions (Approx.)	3 1/2 x 5 1/4 x 1 3/16in (86 x 131 x 29mm)
Weight (Approx.)	1.8 oz (49g)
General	
Case Type	Hand/belt
Function	Protective case for camera
Material	Nylon
Type of Use	Hand/belt bag

© 2013 Sony Electronics Inc. All rights reserved. Reproduction in whole or in part without written permission is prohibited. All other trademarks are property of their respective owners. Features and specifications are subject to change without notice. Non-metric weights and measures are approximate. / UPC:027242853423 / Updated: February 18, 2014